



Characterization of Encapsulated Corrosion Inhibitors for Environmentally Friendly Smart Coatings

2014 INTERNATIONAL WORKSHOP ON
ENVIRONMENT AND ALTERNATIVE ENERGY
"Increasing Space Mission Resiliency through Sustainability"
October 21-24, 2014
Kennedy Space Center, FL

Benjamin Pearman, Wenyan Li, Jerry Buhrow, Xuejun Zhang, Jan
Surma, Lilly Fitzpatrick, Eliza Montgomery & Luz Marina Calle


NASA Kennedy Space Center Corrosion Technology Laboratory

Corrosion

- Worldwide corrosion cost: \$2.2 trillion (2010)
- US cost: ~\$1 trillion (2013)
- Replace current corrosion inhibitors with environmentally friendly alternatives
 - Coating compatibility issues
 - Solubility issues





Delivery System







KSC Approach

- “Smart coating” for corrosion sensing and control
 - Autonomous
 - pH controlled
 - Universal



Emulsion Polymerization




Release Video




RELEASE STUDIES

Inhibitor Release


- Determine release of inhibitor with time
 - 2-Mercaptobenzothiazole (2-MBT)
 - Nitrite
 - Molybdate
- Method
 - Immersion of particles into 0.01 M base
 - Sampling at regular intervals




MF: 2-MBT Short-term Release




MF: 2-MBT Long-term Release




Inorganic: 2-MBT



Inorganic: Nitrite



Inorganic: Molybdate



Release Studies

- Successful encapsulation and release of inhibitor
- Organic particles
 - Inhibitors can react with particle material
 - Slower, longer-term release
- Inorganic particles
 - Can incorporate a variety of inhibitors, including highly water soluble ionic compounds
 - Quicker, higher amount release


ELECTROCHEMICAL CORROSION TESTING

Accelerated Corrosion Testing


- Carbon steel in 3.5% NaCl solution
- Electrochemical measurements
- Salt immersion
 - Phenylphosphonic acid (PPA)
 - 8-Hydroxyquinoline (8-HQ)
 - 2-MBT & Sodium 2-Mercaptobenzothiazole (2-MBTNa)



Corrosion Potential Increase































Polarization Resistance































SALT IMMERSION TESTING





















Pure Inhibitor: PPA

Time	Control	0.1% PPA	0.1% PPA and 0.1% 8-HQ	0.1% PPA and 0.002% 2-MBT	0.1% PPA and 0.1% NaMBT	0.1% PPA, 0.1% 8-HQ and 0.002% 2-MBT	0.1% PPA, 0.1% 8-HQ and 0.1% NaMBT
Initial							
5 hour							
6 day							
After Wash							





















Pure Inhibitor: 8-HQ

Time	Control	0.1% 8-HQ	0.1% 8-HQ and 0.002% 2-MBT	0.1% 8-HQ and 0.1% NaMBT	0.1% PPA and 0.1% 8-HQ	0.1% PPA, 0.1% 8-HQ and 0.002% 2-MBT	0.1% PPA, 0.1% 8-HQ and 0.002% NaMBT
Initial							
5 hour							
6 day							
After Wash							





















Pure Inhibitor: 2-MBT

Time	Control	0.002% 2-MBT	0.1% PPA and 0.002% 2-MBT	0.1% 8-HQ and 0.002% 2-MBT	0.1% PPA, 0.1% 8-HQ and 0.002% 2-MBT
Initial					
4/5 hour					
1 day					
Steel Piece					





















Pure Inhibitor: 2-MBTNa

Time	Control	0.1% NaMBT	0.1% PPA and 0.1% NaMBT	0.1% 8-HQ and 0.1% NaMBT	0.1% PPA, 0.1% 8-HQ and 0.1% NaMBT
Initial					
1 hour					
1 day					
Steel Piece					





















Particles: PPA

Time	Control	0.3% PPA Particles	0.3% PPA Particles 0.25% 8-HQ Particles	0.3% PPA Particles 0.004% 2-MBT Particles	0.3% PPA Particles 0.25% 8-HQ Particles 0.004% 2-MBT Particles
Initial					
1 day					
6 day					
Before Wash					

Particles: 8-HQ

Time	Control	0.25% 8-HQ Particles	0.3% PPA Particles 0.25% 8-HQ Particles	0.25% 8-HQ Particles 0.004% 2-MBT Particles	0.3% PPA Particles 0.25% 8-HQ Particles 0.004% 2-MBT Particles
Initial					
1 day					
6 day					
Before Wash					




Particles: 2-MBT

Time	Control	0.009% Inorganic 2-MBT Particles	0.3% PPA Particles 0.004% 2-MBT Particles	0.25% 8-HQ Particles 0.004% 2-MBT Particles	0.3% PPA Particles 0.25% 8-HQ Particles 0.004% 2-MBT Particles
Initial					
1 day					
6 day					
Before Wash					


Conclusion

- Successful encapsulation of various inhibitors into organic & inorganic microparticles
 - Release of inhibitor monitored over long periods of time → short- and longterm controlled release
 - Corrosion protection of pure materials confirmed through electrochemical testing
 - Particles effective at preventing corrosion in salt immersion testing
 - Inhibitors combinations showing high corrosion inhibition efficiency
-

Synthesis: Organic Particles



Pure Inhibitor Solution pH



pH Change during Polarization

